

SCHOMBURG GmbH & Co. KG Aquafinstrasse 2–8 D-32760 Detmold - Germany phone +49-5231-953-00 fax +49-5231-953-108 mail export@schomburg.de www.schomburg.de/en



# **Technical Data Sheet**

# ASO®-Unigrund-GE Ready to use primer

Art.-No. 2 05536

#### **Properties:**

- Rapid drying
- Universal application
- Resistant to water and alkalis
- Solvent free



#### Areas of application:

ASO-Unigrund-GE reduces the absorption of substrates, binds surface dust, consolidates, prevents rapid water loss from levelling compounds.

ASO-Unigrund-GE is used for priming absorbent and lightly sanded substrates e.g. gypsum-based construction materials (plaster, interlocking gypsum slabs, boards, screeds), concrete, masonry work and similar. Suitable as an adhesion promoter for surface applied waterproof membranes (e.g. SANIFLEX, AQUAFIN-2K/M), thin-bed adhesives such as LIGHTFLEX, MONOFLEX-XL, SOLOFLEX, AK7P, UNIFIX as well as wall and floor levelling compounds such as SOLOCRET-15, SOLOPLAN-30 and ASO-NM15. It is also suitable for exterior use.

#### **Technical Data:**

Basis: acrylate dispersion colour: coloured green

Application/substrate temperature: +5° C to +30° C

Specific gravity: 1.0 g/cm<sup>3</sup>

Cleaning: whilst still fresh, with water Storage: frost free, 15 months in the

original unopened packaging. Use opened packaging promptly.

Packaging: 1, 5, 10, 25, 210 and 1,000 litre containers

Consumption: approx.  $200 \text{ g/m}^2$ 

## **Substrate preparation:**

The substrate must be load-bearing, clean, dry and free from materials, which will impede adhesion. Flow screeds must be abraded and vacuumed. Remove unstable or weakly bonded layers e.g. release agents, residues of old adhesive, levelling layers, surface finishes and paints, by mechanical scrubbing, planing, scabbling or shot-blasting.

### **Product preparation:**

ASO-Unigrund-GE is ready to use. Application is with a paint brush, brush or a fine-pored sponge roller but it can also be sprayed with suitable equipment. Avoid applying too thickly or forming puddles.

ASO-Unigrund-GE must be fully dry before further work

ASO-Unigrund-GE must be tully dry before turther worl can be carried out on the primed surface.

#### **Advice:**

- The primer must be dry before applying the next coat.
- Protect areas not being treated with ASO-Unigrund-GE.
- Do not apply wet in wet.
- Wash off splashes immediately.

Please observe a current valid EU Health & Safety Data Sheet.

GISCODE: M-GP01

